

# Wood & Cork Floor Cleaner



## 1 PRODUCT DESCRIPTION

A solvent-free cleaning agent for the daily cleaning of wood and cork floors. Dissolves dirt intensively and forms a carefully balanced cleaning and care system, in combination with Wood & Cork Polish satin or mat. Also for use directly following the final cleaning of a new building, after such floors have been laid.

## 2 AREAS OF APPLICATION

For the regular cleaning of all sealed wood and cork floors

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

## 3 METHOD OF APPLICATION

Dilute Wood & Cork Floor Cleaner in a ratio of 1:200 (50 ml to 10 l of water) and lightly damp wipe over the floor with this solution. For larger surface areas use a dilution up 1:200 to 1:400 using the spray-cleaning method in combination with a monodisc machine such as the SRP 1 plus a white or red pad.

Remove grease marks and other dirt sticking to the floor with undiluted Wood & Cork Floor Cleaner and a non-abrasive white pad. Afterwards rinse thoroughly with clear water using a wrung-out cloth.

**Note:** Wood and parquet floors are natural products and should never be exposed to damp or even wetness for longer periods of time since they can absorb water and change their shape as a result (swelling). Therefore always only lightly damp-wipe such floors (i.e., using well wrung-out cloths) and ensure that no "pools" are created on the floor.

## 4 CONSUMPTION

Daily Cleaning: 0,1 litre per 100 m<sup>2</sup> (dilution 1:200)

## 5 STORAGE

Store in cool, dry conditions in well sealed receptacles. Store under lock and key and out of the reach of children.

## 6 TECHNICAL DATA

Ingredients: contains under 5% anionic tensides, under 5% ionic tensides. Contains preservatives (METHYLCHLOROISOTHIAZOLINONE, METHYLISOTHIAZOLINONE, BRONOPOL).

pH value: 9,0 – 9,5 (concentrate)

ADR/RID: no dangerous good according ADR.

CLP: GHS07. Danger. H319 Causes serious eye irritation

## Wood & Cork Floor Cleaner



P101 If medical advice is needed, have product container or label at hand. P102 Keep out of reach of children. P280 Wear eye protection / face protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P337+P313 If eye irritation persists: Get medical advice/attention P501 Dispose of contents/container in accordance with local/regional/national/international regulations.

EUH208 Contains mixture of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7] and 2-methyl-2Hisothiazol-3-one [EC no. 220-239-6] (3:1) mixture of: 5-chloro-2-methyl-4-isothiazolin-3-one [EC no. 247-500-7]

Even when using low-pollution products, the usual safety measures are to be observed. Keep away from children. Completely emptied canisters can be disposed of in domestic waste, or taken to a recycling centre.

### 7 SPECIAL NOTES

Please pay attention to our technical instructions specifically for floors and buildings under [www.dr-schutz.com](http://www.dr-schutz.com)

### 8 CROSS-REFERENCE

Our following publications in their updated form are valid as an integral part of this fact sheet:

- General notes on the application of Dr. Schutz finishes
- Safety data sheet available on request.

The quoted printed matter, as well as this product information in its updated form, is available on our homepage [www.dr-schutz.com](http://www.dr-schutz.com) or on request from the address quoted below.

#### Dr. Schutz – We Care About Floors

Headquarter  
Dr. Schutz GmbH  
Holbeinstraße 17  
D-53175 Bonn  
Tel.: +49 (0)228 / 95 35 2-40  
Fax: +49 (0)228 / 95 35 2-46  
E-Mail: [export@dr-schutz.com](mailto:export@dr-schutz.com)  
[www.dr-schutz.com](http://www.dr-schutz.com)

UK  
Dr. Schutz U.K Ltd.  
Unit 24, Anglo Business Park,  
Smeaton Close, Aylesbury Bucks  
HP19 8UP

Contact: Richard Nelson  
Tel.: +44 (0)1296 437827  
Fax: +44 (0)1296 334219  
E-Mail: [richard@dr-schutz.com](mailto:richard@dr-schutz.com)

Ireland  
Dr. Schutz Ireland  
35 Pic Du Jer Park,  
Ballinlough, Cork

Contact: Paul O'Reardon  
Mobile: 0877678388  
E-Mail: [drschutzireland@gmail.com](mailto:drschutzireland@gmail.com)

North America  
Schutz NA  
4701 Bath St 46  
Philadelphia, PA 19137  
USA

Contact: Sam Jamison  
Tel.: +1(877) 272- 4889  
Mobile: +1(215) 510- 7874  
E-Mail: [sam@schutzNA.com](mailto:sam@schutzNA.com)

The above advice for technical application is given to the best of our knowledge and according to the latest state of technology. Therefore, if our products are used carefully heeding the advice given on their application, as well as following our suggested procedures with the materials intended for use with these products, no damage shall occur. However, our products are used outside and beyond our possible control, and are therefore subject to your own responsibility, which does not release you from the obligation to check for yourself whether our supplied products are suitable for your intended purpose and procedure. Therefore our notes and advice are not legally binding and cannot be used against us as grounds for liability - which includes the rights and protection of any third party. The relevant recommendations, guidelines and standard norms are to be observed, as well as the recognized technical rules. On publication, this product information replaces and supersedes the validity of any previous versions.